

## Nähmaschinenengewinde Nähnorm 100

Außen- durchmesser Inch	Außen- durchmesser Bolzen mm	Kern- durchmesser Bolzen mm	Außen- durchmesser Mutter mm	Kern- durchmesser Mutter mm	Gänge je Inch	Steigung mm
5/64"	1,984	1,468	2,013	1,554	64	0,397
3/32"	2,381	2,051	2,399	2,106	100	0,254
3/32"	2,381	1,791	2,414	1,889	56	0,453
1/8"	3,175	2,425	3,217	2,550	44	0,577
9/64"	3,572	2,748	3,618	2,885	40	0,635
11/64"	4,366	3,542	3,412	3,679	40	0,635
3/16"	4,763	4,731	4,820	4,903	32	0,796
3/16"	4,763	3,591	4,828	3,786	28	0,907
15/64"	5,953	4,781	6,018	4,976	28	0,907
1/4"	6,350	5,526	6,396	5,663	40	0,635
9/32"	7,144	5,494	7,236	5,769	20	1,270
9/32"	7,144	5,972	7,209	6,167	28	0,907
5/16"	7,938	6,104	8,040	6,410	18	1,411
3/8"	9,525	8,353	9,590	8,548	28	0,907
7/16"	11,113	9,941	11,178	10,136	28	0,907
9/16"	14,288	12,638	14,380	12,913	20	1,270

